



MicroPython

Introduction (cont.)

MCHE 201 – Spring 2018

Dr. Joshua Vaughan

Rougeou 225

`joshua.vaughan@louisiana.edu`

`@Doc_Vaughan`

In-class Exercise 7



- Attach a potentiometer
- Have the servo angle track the angle of the potentiometer

In-class Exercise 7 Setup



```
import pyb # import the pyboard module
import time # import the time module

# Here, we will use the first position on the pyboard
servo1 = pyb.Servo(1)

# Define constants for the min and max servo angles
MAX_SERVO_ANGLE = 75
MIN_SERVO_ANGLE = -75

# Set up the ADC for the potentiometer
pot_adc = pyb.ADC(pyb.Pin("X22"))
```

In-class Exercise 7 Angle Conversion



```
def potADCtoServoAngle(ADC_value):
```

```
    """ This function converts a potentiometer reading of 0-4095 to an angle
    between MIN_SERVO_ANGLE and MAX_SERVO_ANGLE, using the global
    representation for those angle extremes
```

```
    The middle of the potentiometer range, 2048, should map to 0deg
```

```
    The max. of the range, 4095, should map to MAX_SERVO_ANGLE
```

```
    The min. of the range, 0, should map to MIN_SERVO_ANGLE
```

```
    Inputs:
```

```
        ADC_value : a number between 0 and 4095 representing a reading
                     from the potentiometer
```

```
    Returns:
```

```
        angle : The angle to move the servo to to match the potentiometer angle
    """
```

```
    # define the slope and intercept for the line mapping ADC_value to angle
```

```
    slope = (MAX_SERVO_ANGLE - MIN_SERVO_ANGLE) / 4095
```

```
    intercept = -slope * 2048
```

```
    # Now, calculate the angle output based on that linear function
```

```
    angle = slope * ADC_value + intercept
```

```
    return angle
```

In-class Example 7 Main Loop



```
# Now read the pot and move the servo every 10ms, forever
while (True):
```

```
    # Read the value of the potentiometer.
```

```
    # It should be in the range 0-4095
```

```
    pot_value = pot_adc.read()
```

```
    desired_angle = potADCtoServoAngle(pot_value)
```

```
    # print out the values, nicely formatted
```

```
    print("The ADC value is {:d}.".format(pot_value))
```

```
    print("Moving to {:.2f} deg".format(desired_angle))
```

```
    servo1.angle(desired_angle)
```

```
    # Wait 10ms before looping again
```

```
    time.sleep_ms(10)
```

Controlling Timing



```
# Import time module
```

```
import time
```

```
# sleep for 1 second
```

```
time.sleep(1)
```

```
# sleep for 500 milliseconds
```

```
time.sleep_ms(500)
```

```
# sleep for 10 microseconds
```

```
time.sleep_us(10)
```

**The time.sleep
family of functions
sleep the processor.**

Time Comparison



- Get the current time (to the ms or μ s) using `time.ticks_ms()` or `time.ticks_us()`
- Do time math using `time.ticks_add()` and `time.ticks_diff()`
 - `time.ticks_add(ticks, delta)` calculates `ticks + delta` # Units must match
 - `time.ticks_diff(ticks1, ticks2)` calculates `ticks1 - ticks2`
- More info at: <http://docs.micropython.org/en/latest/pyboard/library/utime.html>

In-class Exercise 8




- Connect a pushbutton
- Turn on the green LED
- When the pushbutton is pressed
 - Turn on the red LED
 - Turn off the green LED
- When the button is pressed again
 - Turn off the red LED
 - Turn on the green LED
 - Print the time elapsed between button pressed to the REPL

In-class Exercise 9




- Connect a pushbutton
- Turn on the green LED
- Once the button is pressed the first time, turn off all LEDs.
- Then, turn on 1 LED every 10s until the button is pressed again
- When the button is pressed again, print the time elapsed between button pressed to the REPL
- If more than 5s elapses:
 - Print "You took too long!!!" to the REPL
 - Turn on only the green LED again

MCHE201 Track Connections



Reading the MCHE201 Start Signal



MCHE201 Track Start Signal



- Will be closed for the 30-second trial time, open otherwise
- Works just like holding down that pushbutton for 30 seconds.
- 120VAC outlet is *always* on

In-class Example 10



- Connect
 - a pushbutton
 - the servomotor
- Start the servo at 0deg
- When the pushbutton is pressed, move the servo
- Only allow this to happen once per 30seconds

What will happen?



```
import pyb # import the pyboard module
import time # import the time module

counter = 0 # Set the initial value of the counter

while (True):
    value = 1 / (10 - counter)

    print("Value = {:.4f}".format(value))

    # Sleep 1s
    time.sleep(1)

    # increment the counter by 1
    counter = counter + 1
```

Try... Except



```
counter = 0 # Set the initial value of the counter
```

```
try:
```

```
    while (True):  
        value = 1 / (10 - counter)  
  
        print("Things are running smoothly...")  
        print("Value = {:.4f}".format(value))  
  
        # Sleep 1s  
        time.sleep(1)  
  
        # increment the counter by 1  
        counter = counter + 1
```

If there is an exception (error) here, then...

```
except: # This will catch the exception
```

```
    print("Things are not so smooth anymore.")
```

This will run.

Try... Except... Finally



try:

```
# Stuff to do if all is well
```

except: # This with catch the exception

```
# Stuff to do if there is an exception
```

finally:

```
# Stuff to do when try finishes
```

```
# or there is an exception
```


KEY POINT!!!



- If you are controlling hardware, it is *your* responsibility to ensure it stops safely if errors occur
- For example:
 - Wrap motor control code in try... except... that would stop the motor if any syntax errors occur
 - Wrap linear actuator code similarly
 - Have a master "finally" that turns off *all* actuators if exceptions occur